

## Snap & Tuft Die (WDSNT36 and WDSNT45)

An auxiliary die designed to be used with Osborne button and snap dies. Produces a product with covered button on one side and snap socket on the other. Use to make slipcovers for button tufted furniture, cushions, and pillows that appear permanent but are removable.

### INSTRUCTIONS

1. Make buttons with button die and W-1 machine. Use the following components plus your fabric:



a) **Collet + Snap Cap**



b) Add **Cardboard Wad**



c) Assemble button with **Fabric and Shell**

2. Remove button plate from machine and screw on snap socket die. Drop Snap & Tuft die into base.

3. Place snap socket on snap socket die and fit finished button (upside-down) into Snap & Tuft die.



4. Lay slipcover fabric (upside-down) over button and press on W-1 handle until you feel button “give” to complete the assembly.\*\*\*

\*\*\*Use of a scratch or sewing awl to make a pilot hole for the button post is strongly recommended. This produces a stronger, cleaner attachment.

**C.S. OSBORNE & CO. 125 Jersey Street, Harrison, NJ 07029 USA**  
**www.csosborne.com** **cso@osborne.com**